



## Mizu Bloc MK2 Twin Waterrail 200mm ABS Overhead Matte Black (3\*)

### IMPORTANT NOTE:

Shower must be installed to the requirements of AS/NZS 3500 by a qualified plumber. Your shower comes to you already factory assembled and tested. We do not recommend the dismantling of any internal part of the shower. The shower is factory tested and sealed so as to give the best performance.

### INSTALLATION INSTRUCTIONS:

1. Screw female water inlet connection (18) to pre-installed male-threaded water supply
2. Push diverter body (4) securely in place over o-ring seals (19) on female water inlet connection (18)
3. Fasten set screws in diverter body (4) to ensure secure connection
4. Mark the height of required drill holes for mounting bottom rail fixing (30)
5. **FOR SOLID WALL APPLICATIONS ONLY:** drill out pre-marked fixing hole and insert expansion plug
6. Screw bottom rail fixing (30) to wall and fit rail wall bracket (33) securely in place into rail fixing
7. Fasten set screws in lower rail wall bracket (33) to ensure secure connection
8. Fit overhead rail piece (1) to diverter body (4) using double o-ring connections and set screws
9. Connect shower hose (16), hand shower (13) and bottom rail (17) to complete the installation
10. Open diverter to check for leaks

### CLEANING RECOMMENDATIONS:

We recommend the use of soapy water or approved cleaners. This product should not be cleaned with abrasive materials. Damage caused by any improper treatment is not covered by the product warranty. Refer to Warranty Conditions