



## Mizu Bloc MK2 Single Waterrail Shower 1 Function Matte Black (3\*)

### IMPORTANT NOTE:

Shower must be installed to the requirements of AS/NZS 3500 by a qualified plumber. Your shower comes to you already factory assembled and tested. We do not recommend the dismantling of any internal part of the shower. The shower is factory tested and sealed so as to give the best performance.

### INSTALLATION INSTRUCTIONS:

1. Screw female water inlet connection (1) to pre-installed male-threaded water supply
2. Connect rail to water inlet via water inlet body (8) with set screws (7)
3. Mark the required height of bottom rail fixing
4. **FOR SOLID WALL APPLICATIONS ONLY:** drill out pre-marked fixing hole and insert expansion plug
5. Screw bottom fixing plate (12) securely to wall
6. Fit horizontal rail-mount adaptor (14) to bottom fixing plate via set screw (15)
7. Connect rail to inlet adaptor at the top and rail-mount adaptor at the bottom
8. Connect shower hose (22) and hand shower (20) to complete the installation
9. Operate shower to check for leaks

### CLEANING RECOMMENDATIONS:

We recommend the use of soapy water or approved cleaners. This product should not be cleaned with abrasive materials. Damage caused by any improper treatment is not covered by the product warranty. Refer to Warranty Conditions