

KADO

Kado Era Freestanding Bath 1700mm White

**Note: Please check the surface thoroughly before installing.
Installation of bath will be taken as acceptance of product.**

It is important to install the product in accordance with the recommended installation guide below.

This installation guide does not include full details of waste connection; final decision about installation of waste connection should be taken by a suitably qualified person in accordance with the plumbing code AS/NZS 3500.

Recommended Installation Guide with optional Waste Pipe

1. Pre-prepare sub-floor for bath to provide waste pipe and 40mm trap below floor level. Take into consideration the waste position of the bath from the wall. Make sure the surface the bathtub will be placed on is perfectly flat, clean, free of any excess humidity and offers adequate support.
2. The bath should be supported by all 4 legs and adjust the bath to level with screw down feet pads.
3. The use of a DWV PVC to copper coupling (Rrj) 40mm (product code 1403940) fitted at floor level is recommended.
4. Fit selected waste to bath and ensure waste is sealed around rim with flexible sealant.
5. Inspect thoroughly for leaks.
6. Anchor all bath feet to floor with flexible sealant.

CLEANING RECOMMENDATIONS

We recommend the use of soapy water or approved cleaners.

This product should not be cleaned with abrasive materials.

Damage caused by any improper treatment is not covered by the product warranty - refer to Warranty Conditions

Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference

