

# AXA

## AXA FIVE RIMLESS CC BTW TOILET SUITE

### INSTALLATION INSTRUCTIONS

#### Note

All measurements for roughing in should be taken from finished wall/floor. Dimensions shown are nominal measurements only.

1. Rough in positions of water inlet and waste outlet (fig 1). Ensure Inlet connection extends 40mm from finished wall.
2. Mark out and drill floor fixing brackets into position (105mm apart, 200mm from the finished wall). Mark out and prepare plate, rod and plastic bend if installing the waste through the floor (fig 3).
3. Fit foam seal to cistern and fit onto the pan. Use the fixing screws to secure it into position.
4. For S trap - Prepare waste outlet according to the required setout (180 min-280 max). Insert 'S' bend into pan collar, fix the pan bend connector back to the wall using the rod and bracket (fig 3).
5. P Trap installation - Set up waste pipe and cut to length. Align and push pan back to wall, connecting pan spigot into pan waste bend. Install cistern to pan.
6. Ensure that pan is level and that cistern aligns with wall. Make minor adjustments if necessary.
7. Bucket flush and check for leaks.
8. Connect rear water inlet valve and flexible hose with elbow (supplied). So that the flexible hose does not touch the water surface (pict.1). Fill the cistern and ensure correct water level. For adjustment refer separate instructions for inlet valve.
9. Fix pan to floor using screws and caps provided.
10. Seal around base of pan with flexible sealant.

Installation of Toilet Seat and Cleaning (separate instructions enclosed)

It is recommended that toilet seat and cover be installed after all trades are finished. The high quality vitreous china finish on this sanitary ware can be maintained by simply using mild soapy water and wiping over. No abrasive cleaners or chemicals should be used on vitreous china surface or toilet seats as this may lead to surface damage.

Do not use any toilet cleaners in the cistern. As the chemical compound may effect the internal mechanisms.

